

Setting Instructions for ACES Humaniac™ 30D and 36D Trap

1. Raise the bar that goes across the front door of the trap all the way to the top.
2. Pull the front door towards you.
3. Move the trip plate rod (the long rod that runs horizontally across the inside of the trap) counter-clockwise.
4. Set it against the bar located on the inside top left hand side of the front door. See Figure 1
5. Move the front door down until it touches the trip plate rod and stays propped open. See Figure 2.
6. We recommend a small trail of bait going from outside the trap to behind the trip plate for best results.

Hint: Depending on where you set the trip plate rod against the bar on the front door will determine the sensitivity of the trap. If you set it as far down as possible, it will be more sensitive and the trap will trip a lot easier. If you set the bar up higher it will require more weight to trip.

Figure 1



Figure 2

